


ADDITIONAL 1/4" UPWARD  
ADJUSTMENT ONLY

THE WOOD BLOCKING MUST BE THE SAME  
LENGTH AS THE TRACK

NET DOOR HEIGHT FORMULA:  
 TOP OF FRAME (TRACK) TO SLAB  
 SUBTRACT 2-5/8" FOR THE TRACK  
 SUBTRACT THE THICKNESS OF THE FINISHED FLOORING  
 SUBTRACT A 1/2" UNDERCUT  
 ADD 1/4" PENETRATION AT THE TOP OF THE DOOR



**WilsonPartitions®**

2301 E. Vernon Avenue Vernon, CA 90058 866.443.7258 323.908.5451 Fax	7601 Ambassador Row, Ste 102 Dallas, TX 75247 214.295.2165 214.496.0156 Fax	110 Viaduct Road Stamford, CT 06907 203.316.8033 203.316.0019 Fax
---	--	--